

Rutland, VT

Terminal spec sheet



	Bay 1	Bay 2
Loading	Тор	Bottom
Ultra Low Sulfur Kerosene (Dyed) Availabe October to mid-April	✓	✓
Ultra Low Sulfur Heating Oil	√	✓
Ultra Low Sulfur Diesel (Clear)	√	✓
Ultra Low Sulfur Diesel (Dyed) Available mid-April to October	✓	✓

Address: 120 Post Street Rutland, VT

05701

Hours of operation: Phone: 802.773.6105 24/7, 365 days a year Fax: 802.773.6108

Call our Customer Support Team at 1.866.865.8800 or email us at IOCCustomerSupport@irvingoil.com



Driver orientation training

To ensure all lifts are made easily and safely, we offer training for drivers. Here are the steps to take to attend our training:

STEP 1 - Complete our compliance checklist

Please ensure you have the following documents before your orientation training. Each of these documents must be with you during every visit to our terminal.

Carrier requirements:	Trailer requirements:	Driver requirements:
\square Terminal access agreement	\square Annual visual inspection	☐ Hazard endorsement
☐ Carrier insurance certificate	\square 5 year inspection	☐ TWIC requirements
	☐ Probe certification	☐ Valid driver's license

STEP 2 - Schedule an appointment

To schedule your driver orientation training, please call the Rutland terminal (802.773.6105) more than 24 hours in advance.

STEP 3 - Attend the training

- The driver orientation training takes about one to two hours.
- Training includes an orientation video, review of standards and procedures, site orientation, supervised loads, and compliance checklist.
- To make the orientation faster and more efficient, you may send an experienced driver along with your new driver.
- Drivers must have ten supervised loads and meet our compliance checklist prior to receiving their access card.
- Completion of orientation is required every three years.



If you have any questions, please contact our Customer Support Team at **1.866.865.8800** or by email at **IOCCustomerSupport@irvingoil.com**.

Thanks for your business, and we look forward to serving you.